

## **Primed Start**

Start a simulated product application or prime the booms when tractor is stopped.

### 1. On Time

- Run-time for the application (seconds).

### 2. Speed

- Simulated speed.

### 3. Master switch delay

- The time to hold the master switch in the 'On' position to start the simulation (seconds).

### 4. Resume

- After the On Time finishes and if the tractor is moving continue with normal operation.