

Requirement_ID	Type	Object text	Status	Task_ID	Review_ID	Remarks
IL_ID1	Heading	Access request with key (CAN message Input)	Praposed	IL_NVJA		
IL_ID2	Definition	To accessing the key from user.	Praposed	IL_NVJA		
IL_ID3	Comment	CANCON and CANSTAT Registers to setting CAN bus to Normal mode.,Key_ID,Data registers,Timer,Led	Praposed	IL_NVJA		
IL_ID4	Requirement	Consider access request key as a Can message ID.	Praposed	IL_NVJA		
IL_ID5		then ECU will receive key ID(CAN message), after that it will compare with initial key ID or received key ID.	Praposed	IL_NVJA		
IL_ID6		then it will check it is Authorised key or not if it not matches lamp will blink for 1 second then.	Praposed	IL_NVJA		
IL_ID7		if key matches lamp will blink for 3 seconds.	Praposed	IL_NVJA		
IL_ID8		also as output indication if key matches the buzzer will beep for 3 times.	Praposed	IL_NVJA		
IL_ID5	Heading	Identify Unauthorised key	Praposed	IL_NVJA		
IL_ID6	Definition	Checking authorised key or not.	Praposed	IL_NVJA		
IL_ID7	Comment	CANCON Registers,Key_ID,Data registers,Timer,buzzer	Praposed	IL_NVJA		
IL_ID8	Requirement	If unauthorised key trying to access then it will warns	Praposed	IL_NVJA		
IL_ID9		If unauthorised key trying to access 1st attempt buzzer will beep for 3 times.	Praposed	IL_NVJA		
IL_ID10		If unauthorised key trying to access 2nd time it will beep for 6 times	Praposed	IL_NVJA		
IL_ID11		If unauthorised key trying to access 3rd attempt it will beep continuous	Praposed	IL_NVJA		
IL_ID9	Heading	Door Status (Hardware Input)	Praposed	IL_NVJA		
IL_ID10	Definition	It will check the door locked and unlocked process on that bases lamp will ON and OFF	Praposed	IL_NVJA		
IL_ID11	Comment	Switch1,Switch2,Lamp,Buzzer,Timer.	Praposed	IL_NVJA		
IL_ID12	Requirement	At the same time it will check door status (hardware input).	Praposed	IL_NVJA		
IL_ID13		if input key ID matches then it will check door locked or not if not matches door status will fail and it will not work.	Praposed	IL_NVJA		
IL_ID14		if key matches after that also it will check door status If door is Unlocked then buzzer will give single beep and warning lamp will ON for 3 seconds then it will off.	Praposed	IL_NVJA		
IL_ID15		In the same way if door is locked then warning lamps will ON and OFF for 1 sec for 3 times.	Praposed	IL_NVJA		
IL_ID13	Heading	Storing Data	Praposed	IL_NVJA		
IL_ID14	Definition	Storing the data in memory.	Praposed	IL_NVJA		
IL_ID15	Comment	We have using external memory for storing data.,(EEPROM)	Praposed	IL_NVJA		
IL_ID16	Requirement	Storing the transmitt data and receive data in memory.	Praposed	IL_NVJA		
IL_ID17		store key satus data		IL_NVJA		
IL_ID18		door status data.		IL_NVJA		