

The Greek Alphabet / Engineering Uses

| Name | Upper Case | Lower Case | Uses |
|---------|------------|------------|---|
| Alpha | A | α | Absorption factor, angles, angular acceleration, attenuation constant, |
| Beta | B | β | Angles, common-emitter current-amplification factor, flux density, phase constant, wavelength costant |
| Gamma | Γ | γ | Electrical conductivity, |
| Delta | Δ | δ | Angles, damping coefficient (decay constant), decrement, increment, secondary-emission ratio |
| Epsilon | E | ϵ | Capacitivity, dielectric coefficient, electric field intensity, electron energy, emmissivity, permit tivity, base of natural logarithms |
| Zeta | Z | ζ | Coefficients, coordinates, impedance |
| Eta | H | η | dielectric susceptibility |
| Theta | Θ | θ | Angle of rotation, angles, angular phase displacement, reluctance, thermal resistance, transit angle |
| Iota | I | ι | Inertia |
| Kappa | K | κ | Coupling coefficient, susceptibility |
| Lambda | Λ | λ | , wavelength |
| Mu | M | μ | Amplification factor, magnetic permeability, micron, mobility, permeability, prefix micro |
| Nu | N | ν | Reflectivity |
| Xi | Ξ | ξ | Output coefficient |
| Omicron | O | o | |
| Pi | Π | π | Peltier coefficient, ratio of circumference to diameter |
| Rho | P | ρ | volume density of electric charge |
| Sigma | Σ | σ | Conductivity, Stefan-Boltzmann constant, surface density of charge |
| Tau | T | τ | Period, time-phase displacement, transmission factor |
| Upsilon | Y | υ | Admittance |
| Phi | Φ | ϕ | Angles, coefficient of performance, contact potential, magnetic flux, phase angle, phase displacement, radiant flux |
| Chi | X | χ | Angles |
| Psi | Ψ | ψ | Angles, dielectric flux, displacement flux, phase difference |
| Omega | Ω | ω | Angular frequency, angular velocity, Ohms, resistance, solid angle |