

## Exercise 0: Safety and Reference

**Purpose:** Pre-job brief.


## Instructions

1. Log into lab computers using Saskatchewan Polytechnic Guest Account.  
[myworkspace30@saskpolytech.ca](mailto:myworkspace30@saskpolytech.ca) - [myworkspace49@saskpolytech.ca](mailto:myworkspace49@saskpolytech.ca)
2. If you enter **ANY** personal data, please **DELETE** before leaving.  
e.g., Browser history, logins, etc.
3. Open Arduino IDE.  
Window Key → Type “Arduino IDE”.
4. You will be prompted with several Administrator windows during setup.
5. Cancel all Administrator dialogs.

## Safety

1. **DO NOT** connect GND and VCC directly without a load.  
This is called a short circuit!
2. **DO NOT** touch any metal part of the board with your hands.  
Handle the board using the edges of the acrylic.
3. Be **MINDFUL** of conventional safety.  
e.g., Sharp surfaces, etc.

## Reference



## The Full Arduino Uno Pinout Guide