

Observers

Control Theory, Lecture 10

by Sergei Savin

Spring 2021

■ Measurement

- ▶ How do we know the state?
- ▶ Why information is imperfect?
- ▶ Definition

■ Observation

- ▶ Using the knowledge about dynamics
- ▶ Observer
- ▶ Observer gains

■ Observer Design

■ Observation and Control

- ▶ LTI
- ▶ Stability analysis
- ▶ Change of variables
- ▶ Upper triangular form
- ▶ Separation principle

MEASUREMENT

How do we know the state?

Before we considered systems and control laws of the following type:

$$\begin{cases} \dot{\mathbf{x}} = \mathbf{Ax} + \mathbf{Bu} \\ \mathbf{u} = \mathbf{Kx} \end{cases} \quad (1)$$

But when we implement that control law, how do we know the current value of \mathbf{x} ? Previously we always took it from simulation.

In practice, we take it from *measurement*.

MEASUREMENT

Why information is imperfect?

There are a number of reasons why we can not directly measure the state of the system. Here are some:

- Digital measurements are done in discrete time intervals;
- Unpredicted events (faults, collisions, etc.);
- Un-modelled kinematics or dynamics (links bending, gear box backlash, friction, etc.) making the very definition of the state disconnected from reality;
- Lack of sensors;
- Imprecise, nonlinear and biased sensors;
- Physics, quantum-scale effects and alike;

MEASUREMENT

Definition

Let us introduce new notation. Assume we have an LTI system of the following form:

$$\begin{cases} \dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \mathbf{y} = \mathbf{C}\mathbf{x} \\ \mathbf{u} = \mathbf{g}(\hat{\mathbf{x}}, t) \\ \hat{\mathbf{x}} = \mathbf{o}(\cdot) \end{cases} \quad (2)$$

Then:

- \mathbf{x} is the state (actual or true state)
- \mathbf{y} is the output (actual or true output)
- $\hat{\mathbf{x}}$ is the estimated (observed) state
- $\hat{\mathbf{y}}$ is the estimated (observed) output

Notice that we never know true state \mathbf{x} , and therefore for the control purposes we have to use the estimated state $\hat{\mathbf{x}}$.

OBSERVATION

Using the knowledge about dynamics

Let us consider autonomous dynamical system

$$\begin{cases} \dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \mathbf{y} = \mathbf{C}\mathbf{x} \end{cases} \quad (3)$$

with measurements \mathbf{y} . We want to get as good an estimate of the state $\hat{\mathbf{x}}$ as we can.

First note: dynamics should also hold for our observed state:

$$\dot{\hat{\mathbf{x}}} = \mathbf{A}\hat{\mathbf{x}} + \mathbf{B}\mathbf{u} \quad (4)$$

Therefore if we know the initial conditions of our system exactly, and we know our model exactly, we can find exact state of the system without using measurement \mathbf{y} . We can call it an open loop observation. Unfortunately, we know neither the model nor the initial conditions precisely.

We propose *observer* that takes into account measurements in a linear way:

$$\dot{\hat{\mathbf{x}}} = \mathbf{A}\hat{\mathbf{x}} + \mathbf{B}\mathbf{u} + \mathbf{L}(\mathbf{y} - \mathbf{C}\hat{\mathbf{x}}) \quad (5)$$

with measurements \mathbf{y} . With this observer, we want to get as good estimate of the state $\hat{\mathbf{x}}$ as we can.

Let's define state estimation error as $\varepsilon = \hat{\mathbf{x}} - \mathbf{x}$. We can subtract (3) from (5), to get *observer error dynamics*:

$$\dot{\hat{\mathbf{x}}} - \dot{\mathbf{x}} = \mathbf{A}\hat{\mathbf{x}} - \mathbf{A}\mathbf{x} + \mathbf{L}(\mathbf{y} - \mathbf{C}\hat{\mathbf{x}}) \quad (6)$$

$$\dot{\varepsilon} = (\mathbf{A} - \mathbf{L}\mathbf{C})\varepsilon \quad (7)$$

OBSERVATION

Observer gains

The observer $\dot{\varepsilon} = (\mathbf{A} - \mathbf{L}\mathbf{C})\varepsilon$ is *stable* (i.e., the state estimation error tends to zero), as long as the following matrix is negative-definite:

$$\mathbf{A} - \mathbf{L}\mathbf{C} < 0$$

We need to find \mathbf{L} . Let us observe the key difference between observer design and controller design:

- Controller design: find such \mathbf{K} that $\mathbf{A} - \mathbf{B}\mathbf{K} < 0$.
- Observer design: find such \mathbf{L} that: $\mathbf{A} - \mathbf{L}\mathbf{C} < 0$

We have instruments for finding \mathbf{K} , what about \mathbf{L} ?

OBSERVER DESIGN

General case: design via Riccati eq.

In general, we can observe that if $\mathbf{A} - \mathbf{L}\mathbf{c}$ is negative-definite, then $(\mathbf{A} - \mathbf{L}\mathbf{c})^\top$ is negative-definite too (by definition of the negative-definiteness).

Therefore, we can solve the following *dual problem*:

■ find such \mathbf{L} that $\mathbf{A}^\top - \mathbf{c}^\top \mathbf{L}^\top < 0$.

The dual problem is *equivalent* to the control design problem. We can solve it by producing and solving algebraic Riccati equation, as in the LQR formulation. In pseudo-code it can be represented the following way:

$$\mathbf{L}^\top = \text{lqr}(\mathbf{A}^\top, \mathbf{c}^\top, \mathbf{Q}, \mathbf{R}).$$

where \mathbf{Q} and \mathbf{R} are weight matrices, determining the "sensitivity" or "aggressiveness" of the observer.

OBSERVATION AND CONTROL

LTI

Thus we get dynamics+observer combination:

$$\begin{cases} \dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \hat{\dot{\mathbf{x}}} = \mathbf{A}\hat{\mathbf{x}} + \mathbf{B}\mathbf{u} + \mathbf{L}(\mathbf{y} - \mathbf{C}\hat{\mathbf{x}}) \\ \mathbf{y} = \mathbf{C}\mathbf{x} \\ \mathbf{u} = -\mathbf{K}(\hat{\mathbf{x}} - \mathbf{x}^*(t)) + \mathbf{u}^*(t) \end{cases} \quad (8)$$

where $\mathbf{A} - \mathbf{BK} < 0$ and $\mathbf{A}^\top - \mathbf{c}^\top \mathbf{L}^\top < 0$.

OBSERVATION AND CONTROL

Stability analysis

When we want to stabilize the origin, the dynamics+observer combination can be represented as a single LTI:

$$\begin{cases} \dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \dot{\hat{\mathbf{x}}} = \mathbf{A}\hat{\mathbf{x}} + \mathbf{B}\mathbf{u} + \mathbf{L}(\mathbf{y} - \mathbf{C}\hat{\mathbf{x}}) \\ \mathbf{y} = \mathbf{C}\mathbf{x} \\ \mathbf{u} = -\mathbf{K}\hat{\mathbf{x}} \end{cases} \quad (9)$$

In matrix form it becomes:

$$\begin{bmatrix} \dot{\mathbf{x}} \\ \dot{\hat{\mathbf{x}}} \end{bmatrix} = \begin{bmatrix} \mathbf{A} & -\mathbf{BK} \\ \mathbf{LC} & (\mathbf{A} - \mathbf{BK} - \mathbf{LC}) \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \hat{\mathbf{x}} \end{bmatrix} \quad (10)$$

We can't directly reason about eigenvalues of this matrix. Next slide will show a way to do it with a change of variables.

OBSERVATION AND CONTROL

Change of variables

Let us use the following substitution: $\mathbf{e} = \mathbf{x} - \hat{\mathbf{x}}$, which implies $\hat{\mathbf{x}} = \mathbf{x} - \mathbf{e}$:

Our system had form:

$$\begin{cases} \dot{\mathbf{x}} = \mathbf{A}\mathbf{x} - \mathbf{B}\mathbf{K}\hat{\mathbf{x}} \\ \dot{\hat{\mathbf{x}}} = \mathbf{A}\hat{\mathbf{x}} - \mathbf{B}\mathbf{K}\hat{\mathbf{x}} + \mathbf{L}(\mathbf{C}\mathbf{x} - \mathbf{C}\hat{\mathbf{x}}) \end{cases} \quad (11)$$

Since $\dot{\mathbf{e}} = \dot{\mathbf{x}} - \dot{\hat{\mathbf{x}}}$, we get:

$$\dot{\mathbf{e}} = \mathbf{A}\mathbf{x} - \mathbf{B}\mathbf{K}\hat{\mathbf{x}} - (\mathbf{A}\hat{\mathbf{x}} - \mathbf{B}\mathbf{K}\hat{\mathbf{x}} + \mathbf{L}(\mathbf{C}\mathbf{x} - \mathbf{C}\hat{\mathbf{x}}))$$

$$\dot{\mathbf{e}} = \mathbf{A}(\mathbf{x} - \hat{\mathbf{x}}) - \mathbf{L}\mathbf{C}(\mathbf{x} - \hat{\mathbf{x}})$$

$$\dot{\mathbf{e}} = (\mathbf{A} - \mathbf{L}\mathbf{C})\mathbf{e}$$

Equation for $\dot{\mathbf{x}}$ takes form:

$$\dot{\mathbf{x}} = (\mathbf{A} - \mathbf{B}\mathbf{K})\mathbf{x} + \mathbf{B}\mathbf{K}\mathbf{e}$$

OBSERVATION AND CONTROL

Upper triangular form

Collecting $\dot{\mathbf{x}}$ and $\dot{\mathbf{e}}$ we get:

$$\begin{cases} \dot{\mathbf{x}} = (\mathbf{A} - \mathbf{BK})\mathbf{x} + \mathbf{BK}\mathbf{e} \\ \dot{\mathbf{e}} = (\mathbf{A} - \mathbf{LC})\mathbf{e} \end{cases} \quad (12)$$

In matrix form it becomes:

$$\begin{bmatrix} \dot{\mathbf{x}} \\ \dot{\mathbf{e}} \end{bmatrix} = \begin{bmatrix} (\mathbf{A} - \mathbf{BK}) & \mathbf{BK} \\ 0 & (\mathbf{A} - \mathbf{LC}) \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{e} \end{bmatrix} \quad (13)$$

Eigenvalues of a upper block-triangular matrices equal to the union of the eigenvalues of the blocks on the main diagonal. Hence here, the eigenvalues of the system are equal to the union of eigenvalues of $(\mathbf{A} - \mathbf{BK})$ and $(\mathbf{A} - \mathbf{LC})$.

OBSERVATION AND CONTROL

Separation principle

Since the eigenvalues of the system are equal to the union of eigenvalues of $(\mathbf{A} - \mathbf{BK})$ and $(\mathbf{A} - \mathbf{LC})$, we can make the following observation:

Separation principle

As long as the observer and the controller are stable independently, the overall system is stable too. This is called *separation principle*.

THANK YOU!

Lecture slides are available via Moodle.

You can help improve these slides at:

github.com/SergeiSa/Control-Theory-Slides-Spring-2021



Check Moodle for additional links, videos, tex