


EKO SOLAR WALL LIGHT

INSTALLATION INSTRUCTIONS



MATERIALS IN PACKAGE



The plate



Expansion Screw



Small screws




the nut with cap



Allen Wrench



HOW TO INSTALL



1. Drill 2 holes in on wall with distance 60~65mm as the drawing shows.



2. Place 2 small screws and 2 large stretch screws onto the plate.


*Please note that the concave surface should face outward.



3. Put the 2 pcs expansion screws into the holes and tighten them properly.



4. Put the wall light on the plate and tighten it to the plate with 2pcs of the screw cap.



Installation must be done by qualified professionals.
Lumina Solutions is not liable for damages caused by incorrect installation.