


EKO SOLAR WALL LIGHT

INSTALLATION INSTRUCTIONS



MATERIALS IN PACKAGE



The plate



Expansion Screw



Small screws




the nut with cap



Allen Wrench



HOW TO INSTALL



1. Drill 2 holes in on wall with distance 60~65mm as the drawing shows.



2. Place 2 small screws and 2 large stretch screws onto the plate.

*Please note that the concave surface should face outward.



3. Put the 2 pcs expansion screws into the holes and tighten them properly.



4. Put the wall light on the plate and tighten it to the plate with 2pcs of the screw cap.

