

INSTRUCTIONS FOR CREATING SUBFORM: 2.14-PCP-Quarterly

Follow these steps to create the form fields:

STEP 1: Create a Single Select field

Description: 2.14-Q-PCP-3: Check overload protection and other protections to ensure correct settings. Check alarms and alarm history as a basis for field inspection of mechanical equipment. Record settings at onset of inspection. Change to correct settings. Record new settings.

Options: Yes, No