


TOF sensor grove cable
connect to 4P connector
Not to Atom S3

Power cable clack to
middle connector
"Power in"

4p molex cable to left
Connector
"Power out"

4P molex cable connect
to clack power connector
from "power
out" clack reader pcb



Flow meter to
backside pcb
position not important

3P molex cable from backside pcb
to clack flowmeter connection

Clack Reader v4
connections
for LESS softener (WS PI)

1x i2c grove cable 50 cm
1x 3P molex
1x 4P molex

Chlorinator connector
to "chlorinator" on clack
reader pcb
(not yet delivered /
to be determined)