


V1

It is not easy to damage
ConcritBoard as shown



V2

On the damaged area, slit
the fibremesh to remove
the crumbs



V3

Prepare mortar for
patching



V4

Patch the hole with mortar




V5

Place back the slitted
fibremesh



V6

Add new layer of
fibremesh and smoothed
the surface



V7

ConcritBoard make good !