



## xPro V2 GRBL V0.9 PIN CONFIGURATION

\* - Indicates input pins (held HIGH with internal pull-up resistors)