



# Dipit Coil




to ST1




to St 3



to ST4



to ST5



Switches seen from solder side

Shorten the cables and solder the colours as shown in the drawing

Attention: switches are sensitive against too much heat