


# GOPRO10 Naked Installation illustration


1. GOPRO10 Naked Rear Case x1
2. GOPRO10 Naked Front Case x1
3. Motherboard x1
4. Front Screen Lens x1
5. Front Screen x1
6. BEC x1
7. Screws
  - 1.4\*6mm x6
  - 1.4\*3mm x4
  - 1.4\*8mm x1
8. Thermally Conductive Silicone x2
9. BEC Gasket x2
10. Lens x1
11. FPC Cable x1
12. Cooling Fan x1



1. Rear Case



2. Front Case




3. Motherboard



4. Front Screen Lens



5. Front Screen



6. BEC



7. Screws




8. Conductive Silicone



9. BEC Gasket




10. Lens



11. FPC Cable



12. Cooling Fan




M1.4\*3

1. Install the lens on the front case and fix it with M1.4\*3 screws




Tear off the double-sided tape


2. Install the front screen and cover the front screen lens



3. The CPU motherboard is pasted with thermally conductive silicone




4. Install the motherboard, fix it with 1.4\*3mm screws, and paste the BEC gaskets



5. Install the FPC cable and buckle the cable plug




6. Paste BEC fixed double-sided tape



7. Install the BEC and fix it with a 1.4\*6mm screw




8. BEC is connected to the FPC cable and fastened



9. Double-sided tape is affixed to the cooling fan



10. Install the fan to the rear case



Notice the positive and negative poles

11. Solder the fan power cable to the BEC, 3.3V for the solder tray

1.4\*8mm  
1.4\*6mm



12. Install the rear case