






Exporting NC Code (CAM File)


- 1) Export NC code to floppy (or USB)
 - a) Select only the features in your feature manager that you want in one program
 - i) There should be one program each for roughing, finishing, and spot drilling (drilling is duplicated from the spot drilling program)
 - b) Click this button on your toolbar: 
 - c) If you see this dialog box:



- i) Select yes and return to step b
 - ii) Otherwise continue to step d
 - d) You should see this dialog box:



- i) To view the NC code, click 
 - ii) To export the NC code to a floppy (or USB), click 



- You should see this dialog box:
 - Ensure that the NC output directory is set to “save to other directory” and the directory shown is a: (for a floppy) or your USB drive
 - Also type in a four digit number for the CAM file name
 - Uncheck all boxes under selection other than NC Program
- 2) Repeat for each program you wish to create
 - 3) Save your FeatureCAM file to the floppy (or USB)