



ULTRA SONIC ANEMOMETER

Step 1




Gently Check the Structure and Wiring

Step 2




Joint the Mounting plate with the base of Ultra-Sonic Anemoter

Step 3




Joint the Ultra-Sonic Anemoter Mounting of with Rain Guage Mounting

Step 4



Joint Pole with Rain Guage Mounting

Step 5



Ensure That the height of Ultra sonic should be bit higher than Rain Guage.