



Fan controller from 1500W ebay boost converters.  
 Makes a stable 10v reference going into the thermistor,  
 which makes a resistor divider that goes into a 2.5v reference,  
 so when the temperature rises enough so the voltage at the reference is over 2.5v,  
 the reference pulls low and the PNP transistor turns on  
 and power goes out to the fan.

**SuperBrainAK**

Sheet: /  
 File: AutoFanSwitch.sch

**Title:**

Size: A4 Date: 2020-12-12

KiCad E.D.A. kicad (5.1.5)-3

**Rev: 1**

Id: 1/1