



คู่มือการตั้งค่า



หน้าจอหลัก จะแสดงเวลา



เมื่อค่าน้ำหนัก มากกว่า 100g



หน่วยเวลาครบตามที่ตั้งไว้ หน้าจอจะ
กระพริบ 10 ครั้ง และกลับไปแสดงเวลา
ต้องยกออกแล้ววางใหม่ จึงจะแสดงค่า
น้ำหนักอีกครั้ง

SET TIME ตั้งค่า นาฬิกา กด SETTIME

SET TIME



ต้องการแก้ไข กด ENTER

ENTER

หน้าจอกระพริบ หลังที่ต้องแก้ไข




ต้องการแก้ไข กด 0-9

หลักที่กระพริบ



ต้องการบันทึก กด ENTER

ENTER



Memory ตั้งค่า กด MENU 1 ครั้ง

MENU



ต้องการแก้ไข กด ENTER


ENTER

หน้าจอกระพริบ หลังที่ต้องแก้ไข



ต้องการแก้ไข กด 0-9

หลักที่กระพริบ









ต้องการบันทึก กด ENTER

ENTER

CANCEL

ออก กด CANCEL





TERMINAL

Software : C370 Order : TGM-61028 110V/220VAC			RS485		OUTPUT SUPPLY				
			(slave)		+24 VDC				
			A	B	+	-			
1	2	3	4	5	6	7	8	9	10

Technical Specification

Power Supply	100-240 VAC, 50-60Hz
Display	7 Segment Size 12"
Input	-
Output	-
Memory	EEPROM with Battery
Setting	Remote IF.
Communication	RS232C format Computer

REMARK	
Frame	Aluminum
Color	Black
Model	TGM-61028

APPEND	
Dimension : 1250W x 450H x 100D mm.	
Character	Arial (Font), White PVC Sticker

PRIMUS COMPANY LIMITED.

PRIMUS COMPANY LIMITED. : 119 Soi Srimuang-Anusorn Sutthisamvinijchai Rd., Dindaeng Bangkok 10400
Tel. 0-2693-7005 (Auto 40 Lines) Fax. 0-2277-3565 www.primusthai.com