


VU001

Quad Distribution Amplifier

User/Build Guide



VU001 is a quad distribution amplifier for composite video signals.

When a video signal is sent to the top rca input, the same signal is reproduced on each of the 4 RCA outputs, allowing to display the same signal on multiple monitors/capture cards without loss.


The module can also be used to distribute internal sync to the front panel. There is two jumpers at the back of the module :

XS4/Source : when set on EXT, the module will distribute the signal at the front input, when set to INT, the module will distribute the signal at the « SYNC IN » input on the back of the module.


XS3/75R termination : A 75R can be used to terminate the sync chain if VU001 is the last module in chain (jumper set on ON), else the resistor can be disconnected if VU001 isn't last in chain (jumper set on OFF) and the sync signal can be chained to another module using the « SYNC THRU » output. This jumper has no effect when XS4 is set on EXT.

# Mainboard build


## Resistors



75R



1k



499R


75R : R1, R5, R6, R7, R8, R9

499R : R2, R10

1k : R3, R4, R11

# Mainboard build

## Capacitors/Ferrites



100nF

Ferrites

10uF

100nF : C1, C2

Ferrites : FB1, FB2


10uF : C16, C17

10uF capacitors are polarized, make sur to make the longer leg/positive side of the capacitor match the + marked/square pad on the board (note that C17 + sign is a bit merged with J7).


100nF capacitors and Ferrites are not polarized, can fit either way.

# Mainboard build

## Semiconductors



1N4001



LM6172

1N4001 : D6, D7

LM6172 : U1


Diodes are polarized, make sure that the ring on the diode matches with the line on the circuit board.

LM6172 is polarized, make sure that the notch on the chip matches the notch on the circuit board.


The kit includes sockets for the ICs, you can use it or not, both have pro and cons, the socket allows to remove the chip easily, which can be useful for troubleshooting, however it can add unwanted capacitance on the IC pins.

# Mainboard build


## Connectors




6pin male



10 pin IDC



3pin male



RCA


XS1, XS2 : 6pin male connector  
J7 : 10pin power header  
XS3, XS4 : 3pin male connector  
J1, J2 : RCA

XS1 and XS2 longer pins should be on the solder side of the board, and soldered from the component side.

XS3 and XS4 longer pins should be on the component side, and solder on the solder side (as all the other components except XS1/XS2)

Mind the orientation of J7.






This is how the board should look once all the components are populated. Let's move on to the Control Board.




# Controlboard build

## Connectors



6pin female




RCA

XS1, XS2 : 6pin female connector  
J1, J2, J3, J4, J5 : RCA connector


XS1 and XS2 are soldered on the opposite side of the RCA

# Controlboard build

## Spacers




10mm  
spacers



11mm  
spacer

10mm spacers are mounted on the RCA side  
11mm spacer is mounted on the solder side



The front panel can now be mounted to the control board using 5x M3 6mm screws. Once both board are plugged together (mind the orientation XS1 on the mainboard should match XS1 on the controlboard, XS2 label is missing from the first batch of mainboard). Both boards can now be secured using the last M3 6mm screw.


Testing :

- Set XS3 on OFF, and set XS4 to EXT. Input a composite video signal to the top RCA on the front of the module, the signal should be available on each of the 4 RCA at the bottom
- Set XS3 on OFF, and set XS4 to INT. Input a composite video signal to the SYNC IN input at the back of the module. The signal should be available on each of the 4 RCA at the bottom.

(Here we're using a composite video signal to test, but the goal is to distribute sync, it is however untested at the time I write this guide, as I don't have any modules that outputs sync through RCA, any feedback is welcome)

## About the circuit :

Since the schematic can be a bit hard to read because of the circuit being on two boards and the two jumpers on the mainboard, here is a simplified view of the EXT mode :




R1 is a 75ohm input termination resistor, composite video standard.

R2 is a 499ohm resistor, help reducing settling time as per LM6172 datasheet recommendation.

U1.1 is configured as a non-inverting amplifier, a gain of 2 is set by R3 and R4.

R5 to R8 are 75ohm output termination resistors, composite video standard.

Simplified view of INT mode :



R9 is a 75ohm input termination resistor, that can be set or not using XS3, depending if the module is used at the end of the sync chain or not.

R10 (same as R2)

U1.2 is used a unity gain buffer, R11 is a 1k feedback resistor as per LM6172 datasheet recommendation.

This buffer have been added so the external input and internal sync input terminations are independent, which means that external input will be properly terminated regardless of XS3 setting.

