




Output-stage gain: $(R20/R17+1)*(R24/R22+1)$
Default: gain =1

R19,C24 and R21,C25 set the output filter cut-off frequency
Default: 5 MHz and 10 MHz



R16 and piezo capacitance form a low-pass filter. Change R16 to set the cut-off frequency.

Use as non-inv. amp (R7,R27) or divider (R23,R25) for level adjustment.

Tilman Preuschoff

Atoms-Photons-Quanta, Institut für Angewandte Physik, TU Darmstadt

Sheet: /Piezo_Controller/

File: Piezo_Controller.sch

Title: RedPitaya Lockbox: Piezo Controller

Size: A4

Date: 2020-09-07

Rev: 1.4

KiCad E.D.A. kicad (5.1.5)-3

Id: 3/3