










# Y Movement Limit Switch Assembly



PARTS LIST	
ITEM	PART NUMBER
1	Plastic Body
2	M3 Nut
3	M3x30mm Screw
4	M3 Washer
5	M3 Plastic Washer
6	Makerbot Limit Switch Board
7	M3x8mm Screw

