











Power Connector and Switch Assembly







PARTS LIST	
ITEM	PART NUMBER
1	Connector Case
2	Connector Case Cover
3	Power Connector and Switch
4	M3x10mm Countersunk Screw
6	M3 Washer
8	M3x20mm Screw

PARTS LIST	
ITEM	PART NUMBER
2	Connector Case Cover
3	Power Connector and Switch
4	M3x10mm Countersunk Screw
5	M3 Nut
6	M3 Washer
7	M3 Spring Washer
8	M3x20mm Screw



A (4 : 1)



PARTS LIST	
ITEM	PART NUMBER
1	Connector Case
2	Connector Case Cover
5	M3 Nut
6	M3 Washer
8	M3x20mm Screw

