

G1	Alternator
C1	Battery
31	Battery -
30	Battery +
X1	Data link connector (DLC)
K2	Fog lamp relay
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-I	Fuse box/relay plate, fascia 1
X28-III	Fuse box/relay plate, fascia 2
K93	Glow plug timer relay
K14	Horn relay
S1	Ignition switch
15	Ignition switch - ignition ON
50	Ignition switch - start signal
Y134	Ignition switch key hold solenoid
A11	Multifunction control module
A171	Relay module
K152	Secondary air injection (AIR) pump relay
X92	Shorting link connector
M1	Starter motor
K4	Starter motor relay
A57	Transmission control module (TCM)

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.





