



NOTES:

1. INSTALL SHEET METAL TERMINATION /SADDLE PIECES AT SIDE TERMINATIONS
2. INTERVENING LAYER CAN BE SECOND LAYER OF DUPONT™ TYVEK® WRB, A LAYER OF GRADE D BUILDING PAPER, FELT, RIGID FOAM BOARD OR THE BACKING OF PAPER-BACKED LATH.
3. REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.
4. FASTEN DUPONT™ TYVEK® WRB WITH APPROVED FASTENERS AND SPACING.
5. INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
6. LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN.
7. FOR ADDITIONAL INFORMATION REGARDING PRODUCT INSTALLATION, REFER TO THE APPLICABLE DUPONT™ INSTALLATION GUIDELINE.

SCALE: NOT TO SCALE
 REVISION DATE: 11/1/16
 DRAWING: R-CP-1205-MA

BALCONY LOW WALL
 CEMENT PLASTER



Tyvek.