










# FPV Frame Assembly Guide for TurboBee 136RS V2 KIT



## Accessories list for TurboBee 136RS V2 KIT

|  |                       |   |   |                       |    |   |                |    |
|--|-----------------------|---|---|-----------------------|----|---|----------------|----|
|  | M2*3 Screw            | 2 |  | M2*5 Screw            | 20 |  | M2X7 Screw     | 16 |
|  | M2*23 Screw           | 4 |  | M2 Nylon Nut          | 6  |  | M2X25 standoff | 1  |
|  | M2 Rubber damper(5.6) | 4 |  | M2 Rubber damper(6.6) | 8  |   |                |    |