


SPI Write

```

ASSUMPTIONS:
block_sleep_mode(EM2)
usart_state_machine.
    busy= true
    TXBL IF is
        enabled

```



SPI Read

ASSUMPTIONS:
block_sleep_mode(EM2)
leuart_state_machine.
 busy= true
 TXBL IF is
 enabled

