

[Command Reference](#) > [SCPI Command Reference](#) > [HCOPy Commands](#) > HCOPy:DESTination

### **HCOPy:DESTination** <PrinterName>

Selects a printer name or file as destination for the screen output.

#### **Parameters:**

<PrinterName>                String variable containing the printer name. One of the printers accessible from your PC. The following strings are supported in addition:

'MMEM' - print to file. The file name is defined via `MMEMory:NAME`. The command [HCOPy:DEvice:LANGuage](#) selects the file format.

'DEFPRt' - use default printer, to be selected in the "Printers and Faxes" dialog of the Windows control panel.

\*RST:                        n/a (\*RST does not overwrite the printer destination)

#### **Example:**

```
MMEM:NAME 'C:\Screenshots\Plot1.BMP'
```

Define a printer file name (without creating the file), assuming that .BMP is the current file format (see [HCOPy:DEvice:LANGuage](#)).

```
HCOP:DEST 'MMEM'; :HCOP
```

Select 'Print to file' and create the printer file specified before.

#### **Manual operation:**

See ["To File..."](#)

[Top](#)