P 🔺 R 🔺 D O X"

IP150 and IP150S Upgrading to v5.2.19 Procedure

November 16th 2020 Created by: Razvan Mirodotescu

www.paradox.com

P 🔺 R 🔺 D O X^{**}

Preface

This document will explain the upgrading procedure of the IP150 and IP150S to the latest 5.2.19 firmware.

What's new

The new firmware 5.2.19 comes with the following features and improvements:

- Fixes unsuccessful internet ping generating "IP No Service" trouble
- Implemented module reboot if Swan polling/internet ping/reporting/DHCP lease fail twice (within approximately 15 minutes)

Upgrading procedure

Depending on the bootloader and firmware, there are 3 procedures available:

- 1. Upgrading IP150 v4.xx with bootloader 2.13 or 2.14 to firmware v5.2.19
- 2. Upgrading IP150 v4.xx with bootloader 2.12 to firmware v5.2.19
- 3. Upgrading IP150S v1.xx with bootloader 2.12 to firmware v5.2.19

The bootloader of the IP150 can be checked in Infield, after connecting to the panel/site:

			Ρ		R		D	0	X®
ep 1: Select Communication Settings									
erial Internet GPRS Multi-Serial Static IP									
IP/Panel S/N (if no site is created on the system	n) • IP/DNS (if a site is created on the	system)							
Panel S/N IP password	Site ID	Email Address		IP pa	ssword				
	· · · · · · · · · · · · · · · · · · ·	X		****	***				
ep 2: Select Device(s)									
ep 2: Select Device(s)	🚼 Select All 🛛 🔠 Unselect	t Al				-			
Refresh Sisconnect Via TCP/IP at 57600 baud	Select AI Onselect	t Al			Firmwa	are Ver	SN		Bootloader Ver
Refresh Disconnect Image: Via TCP/IP at 57600 baud Image: Ontrol Panels Image: Image		t Al			Firmwa 4.20.0		SN	1	Bootloader Ver 2.12.001
Refresh Disconnect Via TCP/IP at 57600 baud Control Panels	Product (Family)	t Al					SN	1	and an



P 🔺 R 🔺 D O X^{**}

1. Upgrading IP150 v4.xx with bootloader 2.13 or 2.14 to firmware v5.2.19

IP150 modules with bootloader 2.13 or 2.14 can be upgraded to v5.2.19 with the current Infield 5.5.2 found in Babyware 5.4.8 on our website, as follows:

- Connect to the panel/site with Infield 5.5.2
- Select the IP150 module
- The latest PUF file will be automatically selected
- Click on Start transfer
- Wait until the upgrade finishes

2. Upgrading IP150 v4.xx with bootloader 2.12 to firmware v5.2.19

IP150 modules with bootloader 2.12 cannot be upgraded to v5.2.19 by the standard procedure.

In order to upgrade these modules, please follow this procedure:

- Do a port forwarding for the software port of the IP150 (port 10000 by default)
- Download firmware 5.2.19 file from Paradox website
- Connect to the panel/site with Infield 4.26.4
- Select the IP150 module
- Click on Browse and select the 5.2.19 firmware file
- Click on start transfer
- Wait until the upgrade finishes

Notes:

- This procedure needs a router with NAT loopback feature
- If the router doesn't support NAT loopback, the upgrade should be done from 2 separate networks. The IP150 module should be connected on a network and Infield should be connected on a separate network (hotspot)



P 🔺 R 🔺 D O X^{**}

3. Upgrading IP150S v1.xx with bootloader 2.12 to firmware v5.2.19

IP150S modules with bootloader 2.12 cannot be upgraded to v5.2.19 by the standard procedure.

In order to upgrade these modules, please follow this procedure:

- Set the IP150S to DHCP from the web interface
- Download firmware 5.2.19 file from Paradox website
- Connect to the panel with Infield 5.5.2
- Select the IP150 module
- Click on Browse and select the 5.2.19 firmware file
- Click on start transfer
- Wait until the upgrade finishes

Note:

- This procedure does not need port forwarding or NAT loopback feature