






- 1 Inside rearview mirror
- 2 Cover



P68.40-2203-06

 	Remove/install		
1 	Detach ground line from battery Notes on battery		AR54.10-P-0003GW AH54.10-P-0001-01A
2	Disconnect connector on electrical line from overhead control panel control unit (N70)		AR82.20-P-1000GW
3	Disconnect electrical connector from hands-free system microphone (A67b1)	 The separating point is located above the overhead control panel control unit (N70).	
4	Unclip cover (2)		
5	Remove rearview mirror (1)	 Unclip inside rearview mirror (1) from bracket downward at an angle.	
6	Install in the reverse order		
7	Read out and erase the fault memory using Star Diagnosis		AD00.00-P-2000-04A