

As of xx/xx/xx

## **YYZ / CYYZ (Toronto) (Elev. 569')**

- Contact **N. Apron 122.27** to advise on ground, then ground will switch you to Apron when clear of runways.
- Apron will say something like "Lane 2 to parking".

### **DEPARTURE - E/O 1570'**

- Contact Clearance with PDC code & ATIS.
  - Call **N. Apron 122.27** for push and taxi. Apron will hand off to Ground & Ground will hand off to Tower.
- Departure on **128.8** (See SID).

■ ■ ■ ■ [A/P INDEX](#) / [HOME](#)