



Cura CR-10S Pro CR20 Pro Setting for Cura


1、Open Cura3.X




2、Settings→Printer→Add Printer.



3、Other→Creality CR-10, and change Printer Name.




4、Settings→Printer→Manage Printers.



5、Click Machines Settings.



6、Set Printer Size (CR-10S Pro is 300X300X400mm; CR20 Pro is 220X220X250mm) .



7、Modify Start G-code as shown.