
**NOTES:**

- In general turn anticipation is mandatory.
- EH-waypoints:
  - The purpose of the so-called EH-points is to define unnamed intersections, turning points, positions and so on and to establish tracks in between.
  - EH-waypoints must be considered as an aid for database coding only.
  - EH-waypoints shall not be used in RTF procedures.
- Detailed information concerning ATS-Routes and WPTs see ENR 3, 4 and 6.
- For ATS-ROUTE restrictions see AD 2.22 paragraph 1.4.3.

EH521 52°47'02"N 006°15'24"E  
EH523 52°00'34"N 006°14'50"E

TWR	131.005	Eindhoven Tower
APP	123.180	Rapcon South
ACC	125.930	Dutch MIL
	132.350	Dutch MIL Info
ATIS	126.030	Eindhoven Information
	121.500	General Emergency

MSA BASED ON EHN NDB



AVERAGE VAR 1°E (2015)  
DISTANCES IN NM  
ALTITUDES IN FEET  
DIRECTIONS ARE MAGNETIC  
23.1 SPY 304.2 DME SPY 23.1 NM  
VOR SPY RADIAL 304.2

— SID / STAR  
- - - SID / STAR AS DESCRIBED  
— ATS ROUTE  
— CDR