





# 52 DIL pinout



**XC888 DIL52**

De Nayer Inst.


D. Pauwels


PINOUT, RESET, BOOT, VREF

XC888\_dil2


23/03/2013 21:43:01


Sheet: 1/3







Sheet: 3/3










# XC888 52 DIL PINOUT

## TOP VIEW





### Power select jumper




USB  
powered



V+(pin52)  
powered

### RxD/TxD jumpers

Jumper for USB  
connection to PC  
(P1.0/P1.1)



### Voltage reference select jumper

Jumper for  
internal 5V/3.3V  
reference