






SPI Slave/CH0  
P0.13 : USIC0\_CH0-DX2F : SEL  
P0.14 : USIC0\_CH0-DX1A : CLK  
P0.15 : USIC0\_CH0-DX08 : MOSI  
P2.0 : USIC0\_CH0-DOUT0 : MISO



Copyright Tinkerforge GmbH 2018.  
This documentation describes Open Hardware and is licensed under the CERN OHL v. 1.1.  
You may redistribute and modify this documentation under the terms of the CERN OHL v.1.1. (<http://ohwr.org/cernohl>). This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the CERN OHL v.1.1 for applicable conditions

Copyright (©) 2018, B.Nordmeyer <bastian@tinkerforge.com>  
Licensed under CERN OHL v.1.1

**Tinkerforge GmbH**

Sheet: /  
File: industrial-di4.sch

**Title: Industrial Digital In 4 2.0**

Size: A4 Date: 2018-02-07  
KiCad E.D.A. kicad 4.0.2+dfsg1-stable

**Rev: 2.0**  
Id: 1/1

DRILL DRILL  
DRILL DRILL