






SPI Slave  
P0.13 : USICO\_CH0-DX2F : SEL  
P0.14 : USICO\_CH0-DX1A : CLK  
P0.15 : USICO\_CH0-DX0B : MOSI  
P2.0 : USICO\_CH0-DOUT0 : MISO



DRILL DRILL  
DRILL DRILL

Copyright Tinkerforge GmbH 2023.  
This documentation describes Open Hardware and is licensed under the  
CERN OHL v. 1.1.  
You may redistribute and modify this documentation under the terms of the  
CERN OHL v.1.1. (<http://ohwr.org/cernohl>). This documentation is distributed  
WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF  
MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A  
PARTICULAR PURPOSE. Please see the CERN OHL v.1.1 for applicable  
conditions

Copyright (©) 2023, B.Nordmeyer <bastian@tinkerforge.com>  
Licensed under CERN OHL v.1.1  
**Tinkerforge GmbH**

Sheet: /  
File: industrial-dual-relay.kicad\_sch

**Title: Industrial Dual Relay**

Size: A4 Date: 2023-01-24  
KiCad E.D.A. eeschema (6.0.7)

**Rev: 1.2**  
Id: 1/1