










THESE ARE ALL 5V INPUT SIGNALS

THESE ARE ALL 3V3





Title		
Size	Number	Revision
A4		
Date:	12-01-2021	Sheet of
File:	C:\Users\...\7b - Voltage Protection.SchDocDrawn By:	

All these should be kept close to wherever the Fatty connector goes



Title		
Size	Number	Revision
A4		
Date:	12-01-2021	Sheet of
File:	C:\Users\...\7c - FET Controls.SchDoc	Drawn By:



Title		
Size	Number	Revision
A4		
Date:	12-01-2021	Sheet of
File:	C:\Users\...\7d - Sensors.SchDoc	Drawn By:

1

2

3

4


A

A




B

B




C

C



D

D






Title		
Size	Number	Revision
A4		
Date:	12-01-2021	Sheet of
File:	C:\Users\...\7e - VBATT Stepdown.SchDocDrawn By:	

1

2

3

4



Title		
Size A4	Number	Revision
Date:	12-01-2021	Sheet of
File:	C:\Users\...\7f - CAN.SchDoc	Drawn By:

