

Description

The UNIT JUN R3 is a multifunctional and flexible development board based on the reliable ATmega328P microprocessor. Completely compatible with the UNO-style form factor, it has contemporary improvements including an inbuilt 5×5 NeoPixel RGB LED matrix, USB-C connection, and a JST 1.0 mm 4-pin extension connector compatible with STEMMA QT and Qwiic® ecosystems.

UNIT JUN R3
Rev1.0

License MIT

Key Features

- Microcontroller: ATmega328P (8-bit AVR)
- Memory: 32 KB Flash, 2 KB SRAM, 1 KB EEPROM
- Clock Speed: 16 MHz
- Power Supply: USB-C (5 V) or external DC jack (7–20 V recommended)
- Interfaces: UART, I²C, SPI, PWM, ADC, GPIO
- NeoPixel Matrix: Integrated 5×5 RGB LED Matrix (**WS2812b-1515**)
- Connectivity: USB-C for programming and power
- Form Factor: UNO-compatible (68.6 mm × 53.4 mm)
- Development IDEs: Arduino IDE, PlatformIO
- Onboard Features: NeoPixel matrix, user LED, reset button
- Expansion Connector: JST 1.0 mm 4-Pin (compatible with Qwiic®, STEMMA QT)

Typical Applications

- Prototyping: Rapidly build and evaluate embedded system concepts.
- Education: Ideal for teaching microcontroller fundamentals and electronics.
- Wearables: Compact form factor and flexible power options for portable devices.
- Interactive Displays: Use the integrated NeoPixel matrix for dynamic visual feedback.

Peripherals

Timers/Counters

- 2 × 8-bit Timer/Counter with period register and compare channels
- 1 × 16-bit Timer/Counter with period register, input capture, and compare channels

Communication Interfaces

- 1 × USART with fractional baud rate generator and start-of-frame detection
- 1 × SPI controller/peripheral
- 1 × I²C controller/peripheral (dual mode)

Analog Features

- 1 × Analog Comparator (AC) with scalable reference input

System Features

- Watchdog Timer with independent on-chip oscillator
- Six PWM channels
- Interrupt and wake-up capability on pin change

Board Operation.....	4
Power Supply Options	4
Clock System.....	4
Reset Behavior.....	4
USB-C Interface	4
NeoPixel Matrix Operation	4
I/O Voltage Levels	4
Operating Conditions	4
Ratings	5
Power Consumption.....	5
Getting Started.....	6
Pinout.....	7
Pin Distribution	8
Pin Classification Table.....	9
1. Digital I/O.....	9
2. Analog Inputs	10
3. SPI Pins.....	10
Board Topology	11
Board Dimensions.....	12
Company Information.....	13
Reference Documentation	13
License.....	14

Board Operation

Power Supply Options

- Operates from USB-C (5 V) supply.
- Absolute maximum external input: **20 V**
- Onboard regulator provides stable 3.3 V / 5 V rails for peripherals.
- AVCC pin supplies the analog circuitry (ADC, comparator).

Clock System

- Default clock: 16 MHz crystal oscillator.
- Optional internal oscillator can be used for low-power applications.

Reset Behavior

- Onboard reset button provides manual reset.
- Automatic reset during USB programming via DTR signal.

USB-C Interface

- Provides both programming interface and power input.
- Integrated USB-to-serial bridge for Arduino IDE compatibility.

NeoPixel Matrix Operation

- Integrated 5×5 WS2812b-1515 RGB LED matrix powered by VCC.
- Controlled via a dedicated digital pin D8.
- Requires sufficient current; recommended external supply for heavy use.

I/O Voltage Levels

- Digital I/O operates at 5 V logic (with 3.3 V tolerant inputs depending on board design).
- Analog reference selectable via AREF pin or internal reference.

Operating Conditions

- Typical operating voltage: 5 V
- Recommended temperature range: 0 °C to +70 °C.

Ratings

Power Consumption

Symbol	Description	Min	Typ	Max	Unit	Condition
V_IN max	Maximum input voltage (VIN pin/jack)	7	—	20	V	External DC jack input
V_USB max	Maximum input voltage (USB-C port)	—	—	5.5	V	USB-C connector
I_max	Maximum output current (board level)	1.7	2	2.1	A	Total delivery
I_3V3	Current available at 3.3 V rail	—	600	—	mA	Regulator output
IOH Max	Output high current per GPIO	—	—	8	mA	At VDD – 0.4 V (VOH)
IOL Max	Output low current per GPIO	—	—	8	mA	At VSS + 0.4 V (VOL)

DC Characteristics ATmega328

(TA = –40 °C to +125 °C, VCC = 2.7 V to 5.5 V)

Parameter	Condition	Symbol	Min	Typ	Max	Unit
Input low voltage (except XTAL1 and RESET)	VCC = 2.7 V to 5.5 V	VIL	–0.5	—	0.3 VCC	V
Input high voltage (except XTAL1 and RESET)	VCC = 2.7 V to 5.5 V	VIH	0.6 VCC	—	VCC + 0.5	V
Input low voltage (XTAL1 pin)	VCC = 2.7 V to 5.5 V	VIL1	–0.5	—	0.1 VCC	V
Input high voltage (XTAL1 pin)	VCC = 2.7 V to 5.5 V	VIH1	0.7 VCC	—	VCC + 0.5	V

Getting Started

1. Power the Board

- a. Connect the **UNIT JUN R3** to a computer using a **USB-C cable**.
- b. The board will power up automatically. The onboard LED will indicate activity.

2. Install Software

- a. Download and install the **Arduino IDE** (or PlatformIO).
- b. Ensure the “**Arduino UNO**” board profile is selected, as the UNIT JUN R3 is compatible with the ATmega328P core.

3. Select Port and Board

- a. In the Arduino IDE, go to **Tools → Board → Arduino UNO**.
- b. Under **Tools → Port**, select the COM/Serial port associated with the UNIT JUN R3.

4. Upload Your First Program

- a. Open the **Blink** example sketch (**File → Examples → 01.Basics → Blink**).
- b. Click **Upload** to program the board.
- c. The onboard LED (D13) should begin blinking if the upload is successful.


5. Explore Onboard Features

- a. Try controlling the **5×5 NeoPixel matrix** (D8) with the Adafruit NeoPixel library.
- b. Experiment with the **user button and reset switch**.
- c. Use I²C, SPI, UART, ADC, and GPIO pins for custom sensors and peripherals.

Pinout



PINOUT UNIT JUN R3

Top view



Description:


■ VCC	■ GPIO compatible with Arduino	■ PWM
■ GND	■ I2C	■ Analog reference
■ Reset	■ UART	■ IO Reference
■ Analog pins	■ SPI	■ RGB



Pin Distribution

Pin Label	Function / Notes
D0	RX – Serial Receive
D1	TX – Serial Transmit
D2	Digital I/O – Interrupt capable
D3	PWM – Pulse Width Modulation
D4	Digital I/O
D5	PWM – Pulse Width Modulation
D6	PWM – Pulse Width Modulation
D7	Digital I/O
D8	Digital I/O, Matrix 5x5 Pin Controller
D9	PWM – Pulse Width Modulation
D10	SPI CS – Chip Select
D11	SPI MOSI – Master Out Slave In
D12	SPI MISO – Master In Slave Out
D13	SPI SCK – Serial Clock
A0	Analog Input – 10-bit ADC
A1	Analog Input – 10-bit ADC
A2	Analog Input – 10-bit ADC
A3	Analog Input – 10-bit ADC
A4	I2C SDA – Serial Data Line
A5	I2C SCL – Serial Clock Line
VCC	Power Supply – 5V/3.3V (design)
GND	Ground – Common reference

Pin Classification Table



1. Digital I/O

Arduino Pin	Port Pin	Functionality
D0	PD0	UART RX
D1	PD1	UART TX
D2	PD2	Digital I/O, External Interrupt (INT0)
D3	PD3	Digital I/O, PWM, External Interrupt (INT1)
D4	PD4	Digital I/O
D5	PD5	Digital I/O, PWM
D6	PD6	Digital I/O, PWM
D7	PD7	Digital I/O
D8	PB0	Digital I/O
D9	PB1	Digital I/O, PWM
D10	PB2	Digital I/O, PWM, SS (SPI)
D11	PB3	Digital I/O, PWM, MOSI (SPI)
D12	PB4	Digital I/O, MISO (SPI)
D13	PB5	Digital I/O, SCK (SPI), Onboard LED

2. Analog Inputs

Arduino Pin	Port Pin	Functionality
A0	PC0	ADC0
A1	PC1	ADC1
A2	PC2	ADC2
A3	PC3	ADC3
A4	PC4	ADC4, SDA (I ² C)
A5	PC5	ADC5, SCL (I ² C)

3. SPI Pins

Arduino Pin	Port Pin	SPI Role
D10	PB2	SS
D11	PB3	MOSI
D12	PB4	MISO
D13	PB5	SCK


(Also available via ICSP header)

4. I2C Pins – JST Connector

Arduino Pin	Port Pin	I ² C Role
A4	PC4	SDA
A5	PC5	SCL




Board Topology



Ref.	Description
IC1	ATMEGA 328P Microcontroller
IC2	CH340 USB to Serial Controller
U1	MP1482 5V Step-Down Regulator
U2	AP2112K 3.3V Regulator
SW1	Reset Push Button
L1	Built-In LED
L2	Tx LED
L3	Rx LED
L4	Power On LED
L5	Neopixel Matrix
J1	USB Type-C Connector
J2	5mm DC Barrel Power Jack
J3	QWIIC Connector (JST 1mm)
JP1	Header for GPIOs
JP2	Header for GPIOs
JP3	Header for Power Supply and System Functions
JP4	Header for GPIOs (Analog)
JP5	Header for GPIOs (SPI)



Board Dimensions



Company Information

Company name	UNIT Electronics
Company website	https://uelectronics.com/

Reference Documentation

Ref.	Link
Github Documentation	https://github.com/UNIT-Electronics-MX/unit_jun_r3_development_board
Arduino IDE	https://www.arduino.cc/en/software
CH340 Driver	http://www.wch-ic.com/downloads/CH341SER_ZIP.html
Data Sheet	ATmega Data Sheet
Getting Started	Quick Start Guide

License


MIT License


Copyright (c) 2025 UNIT-Electronics-MX

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.





Title: UE0081 JUN R3

SKU: UE0081

REV: 1.1

Last date time: 10/07/2025 11:15 a.m.

SHEET: 2 of 2

File:

Sheet description:

Author: Alberto Villanueva

