


MOTOR CAR



MATERIAL REQUIRED



ATTACH WHEELS WITH GEAR MOTORS




STICK GEAR MOTOR AND CUSTER WHEEL ON THE ICECREAM STICK AS SHOWN IN PICTURE



JOIN WIRE AND BATTERY CAP WITH THE SWITCH AS SHOWN IN PICTURE

ARSHA SARAF'S LAB



**ATTACH THE TWO ENDS OF WIRES
WITH MOTOR AS SHOWN IN
FIGURE**



**PLACED THE BATTERY ON THE
ICECREAM STICK AND ATTACHED
WITH BATTERY CAP AND MOTOR
CAR IS READY**

ARSHA SARAF'S LAB