

POWER

UART - RS485

SPEAKER

RELAY

MCU

LED 7 SEGMENT

CAN BUS

BUTTON

SENSOR

NOTE

JP7	Enable/Disable Led 7 Segment
JP8	Enable/Disable 8 Led
JP13	Enable/Disable Speaker
JP9	Enable/Disable Relay
JP3	Enable/Disable SPI CAN
JP4	Enable/Disable 120R for CAN
JP5	Connect/Disconnect VR-ADC to pin PE0
JP11	Connect/Disconnect DS18B20 to pin PB1
JP12	Connect/Disconnect IR1838 to pin PB3
JP10	Connect/Disconnect DHT11 to pin PB2
J10	Select PIC16F/PIC18F
J5/J6	Select UART/RS485

LCD16X2-GRAPHIC LCD

LED

ADC

NRF24L01

