



MUST USE DUMB COIL SETUP IN IGNITION SHEET!!!!






rusefi.com

Sheet: /Ignition/  
File: IGN6.kicad\_sch

**Title: UAEFI Ignition**

Size: A4 Date: 2023-11-01  
KiCad E.D.A. kicad-cli 7.0.9-7.0.9-ubuntu22.04.1

Rev:  
Id: 2/5





rusefi.com

Sheet: /Low Side/

File: LS\_weak.kicad\_sch

**Title: UAEF Low Side low current**

Size: A4

Date: 2023-11-01

Rev:

KiCad E.D.A. kicad-cli 7.0.9-7.0.9-ubuntu22.04.1

Id: 5/5



**rusefi.com**

Sheet: /Injector/  
File: INJ6.kicad\_sch

**Title: UAEFI Injector**

Size: A4 Date: 2023-11-01  
KiCad E.D.A. kicad-cli 7.0.9-7.0.9-ubuntu22.04.1

**Rev:**  
Id: 9/5