












**MUST USE DUMB COIL SETUP IN IGNITION SHEET!!!!**





rusefi.com

Sheet: /Ignition/  
File: IGN6.kicad\_sch

**Title: UAEFI Ignition**

Size: A4 Date: 2023-11-01  
KiCad E.D.A. kicad-cli 7.0.9-7.0.9-ubuntu22.04.1

Rev:  
Id: 2/5

Id: 4/5



rusefi.com

Sheet: /Low Side/

File: LS\_weak.kicad\_sch

**Title: UAEF Low Side low current**

Size: A4

Date: 2023-11-01

Rev:

KiCad E.D.A. kicad-cli 7.0.9-7.0.9-ubuntu22.04.1

Id: 5/5





**rusefi.com**


Sheet: /Injector/  
File: INJ6.kicad\_sch


**Title: UAEFI Injector**

Size: A4 Date: 2023-11-01  
KiCad E.D.A. kicad-cli 7.0.9-7.0.9-ubuntu22.04.1

**Rev:**  
Id: 9/5







Sheet: /  
File: hellen1-vr-discrete.kicad\_sch

**Title:**



Size: A4  
KiCad E.D.A. kicad (6.0.8)

Date:


**Rev:**


Id: 1/1




















A

A

B

B

C

C

D

D

E

E

F

F

G

G

H

H

