










nRF52832 Chip and BLE/U.FL




NFCT Antenna







BAT Power Voltage Regulator




Motor Driver Circuit




Battery Charger Level




Battery Charger




Piezo Buzzer Driver Circuit




RGB LED Bank Channel 1




Atomizer Driver Circuit



Button (BLE, Atom_PW, RESET)



Cartridge Sense



Use in Quad-Link Mode 0,1,2,3

MotorEN	MotorEN	M_CHRG	M_CHRG
BuzzerEN	BuzzerEN	M_PGGOOD	M_PGGOOD
Atom_PW	Atom_PW	ATM_EN	ATM_EN
BLE_SW	BLE_SW	nRST	nRST
Cartridge_EN	Cartridge_EN	R_CH1	R_CH1
SDA	SDA	G_CH1	G_CH1
SCL	SCL	B_CH1	B_CH1
		BAT_SENSE_EN	BAT_SENSE_EN
		BAT_SENSE	BAT_SENSE