



Mapping AMP to OBD:

- 1 -> NC
- 2 -> 1
- 3 -> 10
- 4 -> 2
- 5 -> 14
- 6 -> 4/5
- 7 -> 15
- 8 -> 6
- 9 -> 16
- 10 -> 7

TODO

- Add some pots (296UD103B1N) / switches (JS203011CQN)
- Add I2C Analog Digital Converter MAX11612EUA

Adapted in part from

- Pi Wedge B+ by Byron Jacquot (SparkFun)
- CAN Bus Shield by Sukkin Pang (SK Pang Electronics) and Toni Klopfenstein (SparkFun)

Released under the Creative Commons

Attribution Share-Alike 4.0 License

<https://creativecommons.org/licenses/by-sa/4.0/>

TITLE: CAN-Simulator_v1.1

Design by: Julien Vanier

REV:
V1

Date: 6/3/18 5:49 PM

Sheet: 1/1