


A

B

C



D

Use 26AWG ribbon cables to match PCB impedances (approx 89ohm)