



The right and left audio channels are tied together. Using a mono style audio jack will short the right and left channels to ground. Don't do it

SW9 and the 50K A pot use the same shaft  
Volume Control