


INSTRUMENT APPROACH CHART-ICAO

VAR5.8° W

AERODROME ELEV 3
RWY36R THR ELEV 2.6

ZSSS SHANGHAI/Hongqiao


VOR/DME RWY36R



DME (SHA) (NM)	2	3	4.0	5	6	7	8	9
ALT (m)			180	276	372	468		

MISSED APPROACH
Climb straight ahead to 400, turn
LEFT to CGT at 900, continue to
approach or join the holding pattern.
Follow ATC instructions.

TL 3600
TA 3000
3300(QNH ≥ 1031 hPa)
2700(QNH ≤ 979 hPa)



	A	B	C	D	FAF -MAPt 8.5km						
VOR/DME ^{MDA(H)} VIS	140(137) 2200		140(137) 2400	140(137) 2600	GS in kt km/h	80 150	100 185	120 220	140 260	160 295	180 335
CIRCLING ^{MDA(H)} VIS	210(207) 2800	210(207) 3200	240(237) 4400	240(237) 4800	Time min:sec	3:25	2:44	2:17	1:57	1:43	1:31
					Rate of descent m/s	2.2	2.7	3.2	3.8	4.3	4.9
					Changes: VOR, point.						