

STANDARD ARRIVAL  
CHART - INSTRUMENT


VAR5.2° W

D-ATIS 127.65  
APP 119.45 (124.4)  
TWR 118.0 (130.0)

ZSWX WUXI/Shuofang  
RNP RWY21

BEARINGS ARE MAGNETIC.  
ALTITUDES, ELEVATIONS  
AND HEIGHTS IN METERS.  
DME DISTANCES IN  
NAUTICAL MILES.  
DISTANCES IN KM.

TL by ATC  
TA 1800



- A Aircraft shall join in holding procedure at WX306, and descend altitude to approach.
- B If SASAN 2400 aircraft shall join in holding procedure at WX306, and descend altitude to approach.

Changes: D-ATIS