


目视停靠引导系统飞行员指南
Pilot instructions for
Visual Docking Guidance System


20.系统崩溃
SYSTEM BREAKDOWN

In case of a severe system failure, the display will go black, except for a red stop indicator. A manual backup procedure must be used for docking guidance.
如果遇到严重的系统故障，显示器将变黑，并显示红色的停止信息。
这时必须提供人工引导。



21.电源失效
POWER FAILURE

In case of a power failure, the display will be completely black.
A manual backup procedure must be used for docking guidance.
如果遇到电力中断，显示器将完全变黑。这时必须提供人工引导。



Changes: Chart number.