


TYPE A(OPERATING LIMITATIONS)



RWY 05L/23R

DIMENSIONS AND ELEVATIONS IN METERS BEARINGS ARE MAGNETIC

A vertical scale bar with two columns of markings. The left column is labeled 'ft' and ranges from 0 to 500 in increments of 50. The right column is labeled 'm' and ranges from 0 to 150 in increments of 30. The scale is titled 'VERTICAL SCALE 1:2000' at the bottom.



RWY: 05L - 23R			
RWY 05L	DECLARED DISTANCES		RWY 23R
3200	TAKE-OFF RUN AVAILABLE		3200
3200	TAKE-OFF DISTANCE AVAILABLE		3200
3200	ACCELERATE STOP DISTANCE AVAILABLE		3200
3200	LANDING DISTANCE AVAILABLE		3200



LEGEND	
①	OBST NR
⊙	POLE
*	TREE
A	IRON TOWER
T1	TWY

AMENDMENT RECORD		
NR	DATE	ENTERED BY

Changes: VAR, RWY magnetic bearing, OBST