


TYPE A (OPERATING LIMITATIONS)



RWY 11/29

DIMENSIONS AND ELEVATIONS IN METERS BEARINGS ARE MAGNETIC


A vertical scale bar with two columns of markings. The left column is labeled 'ft' and ranges from 0 to 500 in increments of 50. The right column is labeled 'm' and ranges from 0 to 150 in increments of 30. The scale is used to measure the vertical distance of the structure.



RWY11	DECLARED DISTANCES	RWY29
3400	TAKE-OFF RUN AVAILABLE	3400
3400	TAKE-OFF DISTANCE AVAILABLE	3400
3400	ACCELERATE STOP DISTANCE AVAILABLE	3400
3400	LANDING DISTANCE AVAILABLE	3400



1:20000
HORIZONTAL SCALE



LEGEND	
①	OBST NR
⊙	POLE
■	BUILDING

AMENDMENT RECORD		
NR	DATE	ENTERED BY

Changes: New chart.