



1\* IMPORTANT. Do not buy fake chinese VP230 ICs. Take care and use only verify originals Texas Instruments ICs.

2\* Remove 120ohms SMD resistor or cut one of his trace on CAN bus transceiver.

3\* Optional. VCC measure. R2 = R3 and any 10K to 50K at 1%

TITLE: CPX Interface + 2 Band Remote Control		REV: 0.3
Company: SuSoDevs		Sheet: 1/1
Date: 2022-05-01		Drawn By: